Twin Zone with LWC3 2 1 3 RTS 1 HTS 3 **Twin Channel Programmer** S/L CH ON Boiler 2 CH OFF OFF N LWC₃ 2 3 5 8 10 11 12 9 1 **Pump** 3 Amp **Fused Spur Brown Brown Orange Orange** HW CH Zone

NB: ZA6 has extra WHITE wire

Drayton ED18-1

The above diagram is for quidance only, Drayton accept no liability for any loss or damage arising from any errors or omissions that may be inadvertenly contained with in this diagram, equipment manufacturers of associated products should be consulted to confirm compatibility with drayton products prior to installation.

Zone

Valve

Earth

Neutral

White

ZA5 or ZA6



Earth

Neutral

White

ZA5 or ZA6

Valve

by Schneider Electric